




The call application on your iPhone is located in the bottom bar of your home screen. It is a green square with a picture of a handset in it.




The first page is the Favorites. The Favorites page is represented by a star on the bottom of the screen. To add a new favorite, select the plus icon in the top left corner.

Favorites are speed dials for your contacts.




The next page is your Recent Calls. It is represented by a clock icon in the bottom of your screen. Your entire call history is displayed here. Calls in red are missed calls. Tap a call from your history to dial it again.







Next are your contacts. It is represented by a portrait icon inside a circle. You can search contacts using the search bar at the top of the screen. You can add a new contact using the plus sign in the upper right corner of the screen. You can call a contact by opening it and selecting Call.



Next is the keypad. The keypad is represented by a grid of circles. Tap the numbers to dial a number not saved to your contacts. Tap the green circle with a handset icon inside to call.



Next is your voicemail, represented by the tape icon. Once a voicemail box is set up, you can see voicemails listed here. Select a voicemail to listen to it without inputting a password.

